


Improve Your Standard of Care with PinkProtect Positioning Wedges

Refer to your facility's patient positioning protocols prior to use

1

Ensure Proper Patient Location


Align patient's hips with the bed's hinge point (where it bends).



2

Determine Offloading Areas


After rolling the patient on their side, identify (for example) the sacrum and coccyx (where the back curves to mid gluteal).



3

Position the Wedge(s)

Wedges should be placed 2-3" above and below the offloading area.




**Ensure patients are rolled on their side prior to positioning the wedges. Do not force or slide wedges underneath prone or supine patients.*

**Patients only require enough tilt to remove pressure from offloaded areas. Overtilting is not recommended.*

**Always confirm offloading by placing your hand underneath the offloaded area. Offloaded areas should "float" freely without touching the bed surface.*


Additional Options: Seated Position

Follow steps 1-3 and elevate the bed into a seated position. Offloaded areas should maintain a "floating" position. Positioners may need to be adjusted accordingly.



702 Prominence Drive
Pittsburgh, PA 15068 U.S.A.

Tel: 724.337.5500
Fax: 724.337.0555



xodusmedical.com
info@xodusmedical.com

FDA REGISTERED
ISO 13485 CERTIFIED



xodusmedical.com/eifu

LITIFUIC003 R1 5/27/2021
EMERGO EUROPE
Prinsessegracht 20
2514 AP The Hague
The Netherlands